## Adjustment of Flow Control Rotary Cable on 2500 & 5500 Series Kits

- 1. Start by aligning the 3 on the flat with the arrow on the side of hex (see photo 1).
- 2. Install knob on side of tractor so it points to the 3 on the plate (see photo 2).



